



T & E Pumps Parts Breakdown for 108W

Item Number	Name	Quantity
RG6	Rubber Gears - set-6 x 5.750	1
HOU006CR	6" T&E Housing - RG	1
I003-15.25	15.25" Idler for 4000	1
WP002	Wear Plates - Medium	2
B001	Bushing Cap	2
EP001	Medium Endplate	2
B002	Bushings - Inner plate	4
B25	Bushing - 2.5"	3
H001	Hold Down Ring	3
GN002	Grease Nipple Adapters	3
CC001	Combo cap	1
CC002	Combo cap ends	1
NSK AELS206-102	1.125 Insert Ball bearing	1
AR-1592-ED	Seal	6
MDYE 3/8 plug	3/8 plug scre	2
GN001	Grease Nipples	3
G001-64	End Cap Gaskets	4
G002B-64	Durable Gasket-Medium	2
MDP516-114	5/16 x 1 1/4 Dowel Pin	4
MCSH8C516-34P	5/16 x 3/4" GR8 Bolt	16
M008-4000	Keystock for 6" gears	2
O035-7147	O-ring	1
W001	Washer - Aluminum	3
I004-24	Complete Input Assembly w/24"	1
MCSH8C38-134	3/8x1-3/4 Gr8 Bolt	24
G002B-32	Durable Gasket Medium	2
G002BW-64	Wear Plate Gasket	2
EP000	End Plate Insert	4