



T & E Pumps Parts Breakdown for 513WT

Item Number	Name	Quantity
HOU004C5	T&E 2100 Ductile Housing	1
SG4	4"x5.850" Steel Gears	1
WP002	Wear Plates - Medium	1
EP001	Medium Endplate	2
I003-15.25	15.25" Idler for 4000	1
I010-22	Complete Input 22"/telfon seal	1
CC001	Combo cap	1
CC002	Combo cap ends	1
B25	Bushing - 2.5"	3
NSK AELS206-102	1.125 Insert Ball bearing	1
B001	Bushing Cap	2
AR-1592-E0	Seal	3
AR-M35-926	Teflon Seal	3
H001	Hold Down Ring	3
G001-64	End Cap Gaskets	4
G002BW-64	Wear Plate Gasket	2
G002B-64	Durabla Gasket-Medium	2
G002B-32	Durabla Gasket Medium	2
GN001	Grease Nipples	3
GN002	Grease Nipple Adapters	3
W001	Washer - Aluminum	3
M008-2100	Keystock for 4" gears	2
O035-7147	O-ring	1
MCSH8C516-34P	5/16 x 3/4" GR8 Bolt	16
MCSH8C38-134	3/8x1-3/4 Gr8 Bolt	24
MDP516-134	5/16 x 1-3/4 Dowel Pin	4
MDYE 3/8 plug	3/8 plug scre	2
B002	Bushings - Inner plate	4
EP000	End Plate Insert	4
OB-WP002	OB Wearplate w/o cavitation	1